DRYER MOUNTING TEMPLATE

Fix this card to the wall.

Drill 4 holes

(A. B. C. D. 5/16" (8 mm) diameter: 1-3/8" (35 mm) depth.)

Electrical Connection Description

- 1. Secure the base plate on the wall provided.
- 2. The conduit in place by suitable 1/2 inch trade conduit fitting.
- 3. Connections:
 - A. Connect the live wire (black or dark color) to the terminal block marked "L".
 - B. Connect the neutral wire (white or light color) to the terminal block marked "N".
 - C. Connect the ground wire (colored green or green and yellow) to the green screw marked ".

Note that colors of live and neutral wires depend on voltage of supply service.

Mounting heights from bottom of dryer Men 50" (1270 mm) Woman 47" (1194 mm) 35" Children 4-7 years (889 mm) Children 8-10 years 39" (991 mm) Children 11-13 years 43" (1092 mm) Children 14-16 years 47" (1194 mm) Handicapped 40" (1016 mm)

STØRM RIDER



Electrical conduit - Preferred location

39" (100 cm) from floor. (See mounting chart above.)

HandDryerSupply.com | 804-859-2498 | sales@handdryersupply.com